



Subfloor heating and cooling

Subfloor heating and cooling instructions for Deck Art products

Important information before starting

It is **EXTREMELY IMPORTANT** that you read and understand this information completely prior to starting, since improper installation can void the warranties.

Prevention

DO:

- Maintain indoor relative humidity between 40% and 65%. If this preventive measure is not kept, the flooring can crack, split, discolour, crook, bow and delaminate.
- Use felt leg protector pads under all furniture legs.
- Always clean the floor in accordance with the *Care and Maintenance Instructions*.
- Wipe up spills immediately.
- Use a dolly, rolled over plywood when moving heavy objects.
- Apply (slip resistant) runners or area rugs on high traffic areas.
- Use (slip resistant) door mats to keep abrasives such as dirt, grit and sand off the floor.
- Protect the floor from direct sunlight.

deckart pr

21460, Vrbas, Blok Vasilj Koprivice 18 Telefoni: 021/ 794 220, 021/ 794 222

PIB: 111758275 Matični Broj: 65643910 Tekući Račun: 205-0000000272897-77

Web: www.deckart-parquet.com Email: office@deckart-parquet.com



- Replace narrow, hard furniture rollers with wide rubber ones.

DON'T:

- Allow water to retain on the floor.
- Walk on the floor with any hard and/or sharp object protruding from the sole.
- Use cleaning products that are abrasive or contain alkaline, ammonia, bleach, soap, citrus.
- Let furniture stand on the floor on small hard legs.
- Use a steam mop or any machine as you risk damaging the finish of the floor.

Radiant heating is a growing source of heating both in residential and commercial installations. Deck Art flooring can be installed over radiant heat as long as you understand radiant heat and how it can impact wood flooring, what precautions to take, and what type of wood flooring to use.

Prior to installation of Deck Art flooring or radiant heat system it is important that our guidelines are followed in strict accordance.

For the flooring to remain in good condition, the indoor temperature must remain stable. Sudden fluctuations in temperature and relative humidity will cause the flooring to shrink, expand, contract, crack, cup and bow excessively.

A subfloor heating system is a “slow” system; it takes longer for a room to reach the desired temperature and for the heat to dissipate. To minimize the effect that rapid changes in temperature will have on the wood floor, it is recommended that an outside thermostat be installed. Unlike conventional heating systems, which switch on as needed, radiant systems work most effectively and with less trauma to the

deckart pr

21460, Vrbas, Blok Vasilj Koprivice 18 Telefoni: 021/ 794 220, 021/ 794 222

PIB: 111758275 Matični Broj: 65643910 Tekući Račun: 205-000000272897-77

Web: www.deckart-parquet.com Email: office@deckart-parquet.com



wood floor if the heating process is gradual, based on small incremental increases in relation to the outside temperature.

NOTE: Warranty voids can be caused by rugs, carpets, and cupboards with limited space underneath as these can cause the heat to build up, resulting in shrinkage of joints causing cracks.

Deck Art flooring with a top layer of the following wood species can be used in combination with subfloor heating (either as the main source of heat or as additional heating) and subfloor cooling:

- European Oak
- European Ash

The instructions you will need to follow are provided in the following text.

NOTE: In geographic areas that experience extreme climate and humidity conditions, it is natural, due to the inherent properties of wood, for some minor expansion and contraction to occur which could result in visual changes such as gapping or cupping. These occurrences are not covered by warranty but should self-correct with seasonal climate changes. To minimize this visual change it is important that the relative room humidity never comes below 40% or exceeds 65%.

deckart pr

21460, Vrbas, Blok Vasilj Koprivice 18 Telefoni: 021/ 794 220, 021/ 794 222
PIB: 111758275 Matični Broj: 65643910 Tekući Račun: 205-000000272897-77
Web: www.deckart-parquet.com Email: office@deckart-parquet.com



Installation methods

Option 1:

Glue the flooring directly onto the concrete. Make sure that the concrete is form-retaining and level.

NOTE: The subfloor should be flat to within 5mm in 3m radius or 2mm in 2m radius.

If you choose to glue the flooring directly onto the concrete (Option 1) we recommend that you take the following steps:

- Allow sufficient time to pass for the concrete to dry (minimum 60 days) before testing for moisture content.
- Test the concrete for moisture content prior to installing the flooring.
- The acceptable moisture limit is approximately 2%.
- If readings exceed these limits, use an appropriate vapor retarder compatible with the adhesive to be applied.
- Apply a primer compatible with the adhesive and, if necessary (always when below grade) place moisture barrier.
- Using an adequate adhesive, glue the boards on top within 24 hours with the help of a toothed steel adhesive trowel recommended by the adhesive manufacturer.
- Make sure that pressure is applied to the boards for 24 hours after being glued into place using at least a 20kg weight per m².

deckart pr

21460, Vrbas, Blok Vasilj Koprivice 18 Telefoni: 021/ 794 220, 021/ 794 222
PIB: 111758275 Matični Broj: 65643910 Tekući Račun: 205-0000000272897-77
Web: www.deckart-parquet.com Email: office@deckart-parquet.com



How effective is wood as an insulator?

Wood is an outstanding thermal insulator: unlike a stone floor, it does not feel cold. Although wood is slightly slower to heat up, it retains the heat for longer thanks to its excellent insulating properties. However, to ensure good heat emission, the conductivity resistance (R_c value) of the wooden floor should not be too high. This is determined by the thickness and composition of the flooring. If it is established at an early stage that the R_c value of the flooring is more than permitted, the maximum allowable R_c value could be raised. Possible adjustments to inflow and outflow temperature, the centre-to-centre distance of pipes or the thickness of the layer on top of the pipe to the surface of the topping should then be thoroughly assessed.

Technical values

Rc value of the 13mm thick flooring	0,068 m ² K/W
Rc value of the 11mm thick flooring	0,044 m ² K/W

Heating up before laying the flooring

- Before you use the subfloor heating system for the first time, the sand/cement screed should be at least 42 days old. Set the temperature to 20 °C on the first day of use, and then raise it by 5 °C every day.

deckart pr

21460, Vrbas, Blok Vasilj Koprivice 18 Telefoni: 021/ 794 220, 021/ 794 222
PIB: 111758275 Matični Broj: 65643910 Tekući Račun: 205-000000272897-77
Web: www.deckart-parquet.com Email: office@deckart-parquet.com



- Make sure that the supply water temperature does not exceed 45°C. Maintain this maximum temperature for at least 24 hours per centimeter of floor thickness.
- The lowering of the water temperature should also be in increments of 5 °C every 24 hours until you reach a water temperature of 20 °C.
- The entire heating process takes 14 days – ensure good ventilation during this period to allow moisture to escape. Check the concrete for residual moisture after this process. This must not exceed 2% for a concrete subfloor.
- With radiant-heat systems, a pressure test must be performed and documented by a qualified installer prior to beginning the installation of the wood flooring.
- Check heat system manufacturer guidelines.
- The heating system has to be turned off before installation.

Heating up after laying the flooring

When laying the flooring, the concrete temperature should be between 15 °C and 18 °C. Maintain this temperature for at least 5 days after laying, then you can slowly raise the temperature (1 to 2 °C every day) until you reach the desired temperature or the maximum permissible temperature.

- The residual moisture in the floor must be no more than 2% for a concrete subfloor.
- The maximum contact temperature of the concrete subfloor is 28 °C. The contact temperature is the temperature of the surface of the concrete floor, measured 3 heating days after setting the temperature (depending on the depth of the pipes).

deckart pr

21460, Vrbas, Blok Vasilj Koprivice 18 Telefoni: 021/ 794 220, 021/ 794 222
PIB: 111758275 Matični Broj: 65643910 Tekući Račun: 205-000000272897-77
Web: www.deckart-parquet.com Email: office@deckart-parquet.com



Heating during the season

- Raise the temperature very gradually at the start of the heating season, and lower it again very gradually at the end (1 to 2 °C every day).
- To keep the floor as stable as possible, do not create any difference in day and night temperatures
- Seasonal gapping can be expected.

Key points

- The Relative Humidity (RH) in the room must be between 40% and 65%. Measure the RH using a well calibrated measuring hygrometer in a non-draughty room 15 cm above the floor. If the RH is too low, cracks may form.
- It is highly recommended that the radiant heat system be designed specifically to accept a wood floor.
- Use of an in floor temperature sensor as well as a separate thermostat for the individual room is required.
- Radiant heat is dry heat. A humidification system may be necessary to maintain wood flooring in its comfort zone.
- The cover on water pipes must be at least 30mm thick to ensure a good distribution of heat
- The maximum contact temperature of the cement screed is 28 °C.
- Heat the room at a steady temperature.
- Follow the heating protocol before, during and after installation.

deckart pr

21460, Vrbas, Blok Vasilj Koprivice 18 Telefoni: 021/ 794 220, 021/ 794 222

PIB: 111758275 Matični Broj: 65643910 Tekući Račun: 205-0000000272897-77

Web: www.deckart-parquet.com Email: office@deckart-parquet.com



- When you begin to turn up the subfloor heating again in winter, do so gradually (raise the temperature approximately 1 to 2 °C every day).
- Remove all dust and always apply a primer.
- The concrete needs to be of excellent quality. It is essential that 20 kg of pressure per m² be applied to each board immediately after gluing into place.
- Use a two-component adhesive.
- Apply the adhesive using the appropriate trowel recommended by the adhesive manufacturer
- Placing rugs on top often causes discoloured areas; do not place cupboards with no space underneath
- Cracks and shrinkage joints are often caused by insufficient RH and/or an excessively high flooring temperature.
- For a subfloor cooling system, condensation protection must be installed.

Guarantee

We guarantee a stable product and also give a guarantee against delamination, excessive deformation and cracking.

It is necessary to install heat sensors for measuring the subfloor temperature in such a way that they provide permanent access to recorded values through temperature reports during the process of heating.

Installation should be carried out in accordance with the above instructions.

The subfloor cooling system must include condensation protection.

deckart pr

21460, Vrbas, Blok Vasilj Koprivice 18 Telefoni: 021/ 794 220, 021/ 794 222

PIB: 111758275 Matični Broj: 65643910 Tekući Račun: 205-0000000272897-77

Web: www.deckart-parquet.com Email: office@deckart-parquet.com



Cracking that does not exceed the quality description by more than 10% is not covered by the guarantee.

deckart pr

21460, Vrbas, Blok Vasilj Koprivice 18 Telefoni: 021/ 794 220, 021/ 794 222
PIB: 111758275 Matični Broj: 65643910 Tekući Račun: 205-000000272897-77
Web: www.deckart-parquet.com Email: office@deckart-parquet.com